

POLYCOM VVX SERIES MODEL: 201

1. Record the MAC address of the phone you are reflashing
-
2. Press keys 1 – 3 – 0 all at once to initialize reboot
 3. Click Cancel
 4. Press keys 1 – 3 – 5 all at once
 5. Enter MAC of phone as password (entry is case sensitive) using the key below
 - a>1A = lower case
 - 1>Aa = number
 - A>a1 = caps
 6. Select Home key
 7. Press Settings
 8. Press Advanced
 9. Enter password 456
 10. Select “1. Admin Settings”
 11. Select “1. Network Configuration”
 12. Using the up/down arrows, highlight “Provisioning Server” then press Select
 13. Using the up/down arrows, highlight “DHCP Menu” then press Select
 14. Using the up/down arrows, highlight “Boot Server” then press Select
 15. Using the up/down arrows, select “Static” then press Select
 16. Press “Back”, “Back” to Provisioning Server
 17. Using the up/down arrows, highlight “Server Type” then press Select
 18. Using the right/left arrows, select “HTTPS”
 19. Using the up/down arrows, highlight “Server Address “then press Select

20. Using the numeric keypad, enter the following case sensitive URL:
<https://plcm.sipflash.com>

Alpha/Symbol	Key
h	444
t	88
t	88
p	77
s	77777
:	*****
/	#
/	#
p	77
l	5555
c	2222
m	66
.	*
s	77777
i	4444
p	77
f	3333
l	5555
a	22
s	77777
h	444
.	*
c	2222
o	6666
m	66

21. Press the OK softkey
22. Press Back/Left twice to Network Configuration
23. Press the “Yes” soft key to begin the reboot sequence